

SmartCount™ Run Screen Fields by Model

									SC MODEL													
Function/Field Label	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Actual Count 1 (Up)	X	X	X			X	X	X	X	X	X	X	X	X		X	X	X		X	X	
Actual Count 1 (Down)	X	X				X					X											
Actual Count 2							X	X	X								X					
Actual Rate		X		X	X	X			X	X	X	X			X	X	X					X
Target Rate				X	X						X	X			X	X	X					X
Target Count			X							X	X	X		X		X	X			X	X	
Count Percent												X		X		X	X			X		
Rate Percent												X				X	X				X	
Percent Complete													X			X	X				X	
Current Downtime						X									X	X	X	X	X	X		X
Total Down Time															X	X	X	X	X	X		X
Downtime Status																X	X	X	X	X		X
Total (Job/Shift)													X				X				X	
Total-Actual																	X				X	
Average Rate															X							X
Count 1 - Count 2								X									X					
Current Run Time																		X				
Total Run Time																		X				
Shift Downtime															X							
Distance					X																	
Net Percent																	X					